



CPU V2 Module part number **108314**



ST2 is generally not used, port for PLAST-CONTROL service connection to modem or laptop. Opto chips can be moved to ST3 port if those chips are known or suspected bad.

Part number **102110**
4200

Part number **102109**
4100



Note proper location of indicator

* subject to change without notice