


Width measurement bar

Replacing the IR sensors






1
Remove covers



2
Remove Teflon rollers

Caution!
Turn off power supply first!


P/N 111812 - \$270.95
Part consists of IR sensor and circuit board



Plastic sleeves!


LED!
Orientation

Install new sensor and board



5
Adjust gap!

Re-install teflon rollers and covers



Middle position

LED green: stand by

LED yellow: status